



Total Vehicle Protection

Coverage Plan Options




Provided and Administered by:
D.I.S.C.C. Enterprises Ltd.
 P.O. Box 6446, Station Terminal
 Vancouver, British Columbia V6B 6R3

NATIONWIDE PROTECTION
800-663-1303

A toll-free number for fast, courteous service.
 Call for assistance and authorization.
 Our plans are honoured in both Canada and the U.S.

Customer Service & Claims
800-663-1303

Emergency Roadside Assistance
877-558-6684



1	Engine	✓	✓	✓
2	Transmission	✓	✓	✓
3	Hybrid & Electric	✓	✓	✓
4	Transfer Case	✓	✓	✓
5	Drive Axle	✓	✓	✓
6	Seals & Gaskets	✓	✓	✓
7	Steering		✓	✓
8	Suspension		✓	✓
9	Air Conditioning		✓	✓
10	Electrical		✓	✓
11	Chassis		✓	✓
12	Complete Coverage			✓

About Old Republic Insurance Company of Canada
 Old Republic Insurance Company of Canada (www.orican.com) is a Canadian federally licensed Property and Casualty insurer, with our head office in Hamilton, Ontario. We have focused on being an industry leader in the underwriting of long haul trucking insurance and also specialize in the manufacturing and administering of customized, private-label products for distributors of travel, student accident, and disability insurance. Our strengths lie in our high quality products, customer service, and integrated administrative/claims capabilities developed from decades of supporting Canadians.

This brochure highlights the benefits of the Old Republic Vehicle Warranty Plans. Please refer to the actual vehicle warranty policy for coverages, exclusions, terms, conditions, and limitations.



OLD REPUBLIC INSURANCE GROUP

Vehicle Warranty Plans for New and Pre-Owned Vehicles

Extended Protection you can count on from Old Republic

Total Vehicle Protection offers a wide range of new and pre-owned vehicle coverage that compliments your vehicles current factory warranty. Unexpected vehicle repairs are an unfortunate part of life, but with a TVP warranty, the most critical and expensive components of your vehicle are covered. Today, drivers keep their vehicles longer than ever—often leaving themselves unprotected from expenses after their vehicle's factory warranty has expired. With thousands of specialized parts and high-tech components, investing in Total Vehicle Protection eases the potential financial burden of unexpected mechanical and electrical failures.

ADDITIONAL BENEFITS

Included in all levels of coverage:

- ✓ Wear and Tear coverage: All plans cover ordinary wear beyond the manufacturer's specifications and tolerances.
- ✓ One deductible per visit no matter how many components are affected

Our TVP warranty offers protection for your vehicle up to **ten years** & up to **200,000 kilometers**, with coverage beginning the day you purchase your policy. When choosing your TVP warranty, there are multiple levels of coverage, and you get the choice of selecting the one that's right for you.

With **4 levels of new vehicle coverage**, and **3 levels of pre-owned coverage**. All tailored with several time & kilometer options to best suit your:

- Intended years of ownership
- Driving Habits
- Lifestyle
- Vehicle



RENTAL

Rental reimbursement benefits up to \$400 while your vehicle is undergoing covered repairs (see the schedule in your policy).



TRAVEL & LODGING

Reimbursement for meals and lodging when covered failure occurs more than 160 kilometers from home, up to \$150 per day to a maximum of \$450



EMERGENCY ROADSIDE ASSISTANCE

Hassle-free and available on a "sign & drive" basis throughout the US and Canada, 24 hours a day, 365 days a year, up to \$150 per occurrence.


Call 877-558-6684 for the following benefits:

- Towing
- Lock-Out Assistance
- Fuel Delivery Services
- Flat Tire Assistance
- Battery Service



TIRE ROAD HAZARD

Provides coverage for repair or replacement of your vehicle's tires when damaged due to a road hazard.



Providing you with peace of mind on the open road.

Customer Service / Claims: 800-663-1303
 Emergency Roadside Assistance: 877-558-6684

SCHEDULE OF COVERAGE

ENGINE

Supreme Wrap
Supreme
Deluxe
Select

Cylinder Block & Cylinder Heads*	✓	✓	✓	✓
All Internal Parts	✓	✓	✓	✓
Pistons & Piston Rings	✓	✓	✓	✓
Connecting Rods & Bearings	✓	✓	✓	✓
Crankshaft & Crankshaft Main Bearings	✓	✓	✓	✓
OHC Carriers	✓	✓	✓	✓
Camshaft & Camshaft Bearings	✓	✓	✓	✓
Cam Followers	✓	✓	✓	✓
Timing Chain, Belt, Gears	✓	✓	✓	✓
Timing Chain Cover*	✓	✓	✓	✓
Timing Chain Tensioners	✓	✓	✓	✓
Timing Chain and Belt Guides	✓	✓	✓	✓
Timing Belt & Gears	✓	✓	✓	✓
Timing Belt Pulley	✓	✓	✓	✓
Rocker Arms & Rocker Shafts	✓	✓	✓	✓
Rocker Bearings	✓	✓	✓	✓
Cylinder Head Valves	✓	✓	✓	✓
Valve Seals & Valve Seats	✓	✓	✓	✓
Valve Lifters & Valve Springs	✓	✓	✓	✓
Valve Retainers	✓	✓	✓	✓
Push Rods	✓	✓	✓	✓
Water Pump	✓	✓	✓	✓
Oil Pump & Oil Pump Housing	✓	✓	✓	✓
Harmonic Balancer	✓	✓	✓	✓
Oil Pan*	✓	✓	✓	✓
Intake Manifold	✓	✓	✓	✓
Exhaust Manifold	✓	✓	✓	✓
Valve Covers*	✓	✓	✓	✓
Engine Mounts	✓	✓	✓	✓
Seals & Gaskets	✓	✓	✓	✓
External Sensors			✓	✓
Block Heater			✓	✓
Engine Serpentine Belt Tensioner			✓	✓
Flywheel			✓	✓
Diesel Vacuum Pump			✓	✓

RIDE SHARING

	✓	✓	✓	✓
--	---	---	---	---

TURBOCHARGER SUPERCHARGER

Turbocharger Housing & All Internal Parts	✓	✓	✓	✓
Supercharger Housing & All Internal Parts	✓	✓	✓	✓
Seals & Gaskets	✓	✓	✓	✓
Intercooler			✓	✓

TRANSMISSION

Transmission Case* & All Internal Parts	✓	✓	✓	✓
Input Shaft	✓	✓	✓	✓
Torque Converter	✓	✓	✓	✓
Vacuum Modulator	✓	✓	✓	✓
Transmission Mounts	✓	✓	✓	✓
Oil Pan	✓	✓	✓	✓
Seals & Gaskets	✓	✓	✓	✓
Transmission Control Module			✓	✓
External Sensors/Switches			✓	✓
Master Clutch Cylinder			✓	✓

TRANSFER CASE

Transfer Case* & All Internal Parts	✓	✓	✓	✓
Seals & Gaskets	✓	✓	✓	✓
Transfer Case Mounts	✓	✓	✓	✓
Encoder Motor			✓	✓

STEERING

Steering Box & All Internal Parts		✓	✓	✓
Rack & Pinion Gear		✓	✓	✓
Power Steering Pump		✓	✓	✓
Steering Column Shafts		✓	✓	✓
Seals & Gaskets		✓	✓	✓
Power Steering Hoses			✓	✓
Pitman Arm			✓	✓
Idler Arm			✓	✓
Center Link			✓	✓
Relays			✓	✓
Sensors			✓	✓
Steering Damper & Wheel			✓	✓
Variable Steering Assist Components			✓	✓
Power Steering Cooler			✓	✓

FRONT & REAR SUSPENSION

Upper & Lower Control Arms		✓	✓	✓
Control Arm Shafts or Bushings		✓	✓	✓
Upper & Lower Ball Joints		✓	✓	✓
Torsion Bars and Mounts or Bushings		✓	✓	✓
Stabilizer Bar, Links and Bushings		✓	✓	✓
Wheel Bearings		✓	✓	✓
Steering Knuckles		✓	✓	✓
King Pins			✓	✓
Spindle			✓	✓

ELECTRICAL

Supreme Wrap
Supreme
Deluxe
Select

Alternator		✓	✓	✓
Voltage Regulator		✓	✓	✓
Starter Motor		✓	✓	✓
Starter Solenoid		✓	✓	✓
Starter Drive		✓	✓	✓
Electronic Ignition Module		✓	✓	✓
Distributor Pick-Up Coil		✓	✓	✓
Ignition Switch		✓	✓	✓
Ignition Lock Cylinder		✓	✓	✓
Front & Rear Wiper Motor		✓	✓	✓
Power Vent Windows Motors		✓	✓	✓
Power Window Motor		✓	✓	✓
Power Seat Motors		✓	✓	✓
Power Antenna Motor		✓	✓	✓
Convertible Top Motor		✓	✓	✓
Rear Window Defroster Grid		✓	✓	✓
Power Door Lock & Actuator Switch		✓	✓	✓
Manually Operated Switches		✓	✓	✓
Window Regulators		✓	✓	✓
Body Computer & Control Module			✓	✓
Powertrain Control Module			✓	✓
Headlamp Motor			✓	✓
Heater & Air Conditioning Control Assembly			✓	✓
Blower Motor Resistor			✓	✓
Horns			✓	✓
Factory Installed Cruise Control Module			✓	✓
Cruise Control Transducer			✓	✓
Cruise Control Servo & Amplifier			✓	✓
Power Mirror Motor (excluding assemblies)			✓	✓
Sun Roof Motor			✓	✓
Washer Pump & Switch			✓	✓
Complete Vehicle Wiring Harness			✓	✓
Radio, TV, VCR, CD Player, DVD Player			✓	✓
Electronic Transmitting Devices			✓	✓
GPS Navigation Systems			✓	✓
Factory Engine Compartment Wiring Harness			✓	✓
Digital Instrument Cluster			✓	✓
Instrument Panel Printed Circuit Board			✓	✓
Heated Seats			✓	✓
Theft Deterrent System			✓	✓
Daytime Running Light Module			✓	✓

AIR CONDITIONER

Condenser		✓	✓	✓
Compressor		✓	✓	✓
Clutch Assembly & Pulley		✓	✓	✓
A/C Lines & Hoses		✓	✓	✓
Evaporator		✓	✓	✓
High/Low Compressor Cut-Off Switch		✓	✓	✓
Expansion Valve		✓	✓	✓
Pressure Cycling Switch		✓	✓	✓
Orifice Tube		✓	✓	✓
Seals & Gaskets		✓	✓	✓
Idler Pulley		✓	✓	✓
Heated Doors			✓	✓
Mode Actuators			✓	✓
Blend Door Motors			✓	✓

HEATING & COOLING SYSTEM

Water Pump		✓	✓	✓
Seals & Gaskets		✓	✓	✓
Heater Core			✓	✓
Front & Rear Blower Motor			✓	✓
Engine Cooling Fan & Motor			✓	✓
Hydraulic Fan Clutch Hub			✓	✓
Radiator			✓	✓
Hot Water Valve			✓	✓
Resistors			✓	✓
Relays			✓	✓
Coolant Reservoir			✓	✓
Radiator Cap			✓	✓

DRIVE AXLE

Drive Axle Case* & All Internally Lubricated Parts	✓	✓	✓	✓
Axle Shaft	✓	✓	✓	✓
Drive Shaft Universal Joint	✓	✓	✓	✓
Locking Hubs	✓	✓	✓	✓
Drive Shaft	✓	✓	✓	✓
CV (Constant Velocity) Joints	✓	✓	✓	✓
CV Boots	✓	✓	✓	✓
Seals & Gaskets	✓	✓	✓	✓
Hub Bearing Assemblies	✓	✓	✓	✓
Differential Cover			✓	✓
Drive Line Actuators			✓	✓
Final Drive Housing			✓	✓

CHASSIS HARDWARE

Hood Latch		✓	✓	✓
Hood Cable		✓	✓	✓
Door, Hood, Trunk, Hatch Hinges		✓	✓	✓
Glove Box Lock & Hatch		✓	✓	✓
Console Lock & Hatch		✓	✓	✓
Ignition Lock & Tumbler		✓	✓	✓

BRAKES

Supreme Wrap
Supreme
Deluxe
Select

Master Cylinder		✓	✓	✓
Vacuum Assist Booster		✓	✓	✓
Hydro Assist Booster		✓	✓	✓
Disc Brake Caliper		✓	✓	✓
Wheel Cylinders		✓	✓	✓
Compensating Valve		✓	✓	✓
Metal Brake Hydraulic Lines		✓	✓	✓
Combination Valve		✓	✓	✓
Seals & Gaskets		✓	✓	✓
Parking Brake Linkage		✓	✓	✓
Parking Brake Cables		✓	✓	✓
ABS Electronic Control Unit		✓	✓	✓
ABS Wheel/Speed Sensors		✓	✓	✓
ABS Valves		✓	✓	✓
ABS Hydraulic Unit		✓	✓	✓
ABS Accumulator		✓	✓	✓
ABS Modulator		✓	✓	✓
ABS Actuators		✓	✓	✓
ABS Wiring Harness			✓	✓
Relays			✓	✓
Switches & Solenoids			✓	✓
Hydraulic Control Unit			✓	✓

FUEL SYSTEM

Fuel Pump		✓	✓	✓
Fuel Injectors		✓	✓	✓
Electronic Fuel Injection Sensors		✓	✓	✓
Control Unit		✓	✓	✓
Fuel Tank			✓	✓
Mechanical Fuel Tank Sending Unit			✓	✓
Fuel Rail			✓	✓
Fuel Pressure Regulator			✓	✓
Metal Fuel Delivery Lines			✓	✓
Fuel Tank Selector Valve			✓	✓
Fuel Level Sensor			✓	✓
Fuel Gauge			✓	✓

EMISSION SYSTEM

Cam Shaft Sensor		✓	✓	✓
Knock Sensor		✓	✓	✓
Crank Angle Sensor		✓	✓	✓
Idle Speed Control Motor		✓	✓	✓
Mass Air Flow Sensor		✓	✓	✓
O2 (Oxygen) Sensor		✓	✓	✓
Throttle Position Sensor (TPS)		✓	✓	✓
EGR Solenoid			✓	✓
EGR Valve			✓	✓
Manifold Pressure Sensor			✓	✓
PCM Coolant Temperature Sensor			✓	✓
Canister Purge			✓	✓
Air Pump			✓	✓
Canister Solenoid			✓	✓
Canister Vent Solenoid			✓	✓
Vacuum Pump			✓	✓

ELECTRIC & HYBRID DRIVE

Traction Power Inverter Module	✓	✓	✓	✓
Auxiliary Fluid Pump and Controller	✓	✓	✓	✓
Display Monitors	✓	✓	✓	✓
Final Drive Assembly and Internal Parts	✓	✓	✓	✓
Electric Drive Motor(s)	✓	✓	✓	✓
Powertrain Control Modules	✓	✓	✓	✓
Power Controller	✓	✓	✓	✓
High Voltage Wiring		✓	✓	✓
3-phase Cables		✓	✓	✓
Drive Motor Generator		✓	✓	✓
Power Inverter and Control Units		✓	✓	✓
Cooling Fans		✓	✓	✓
High Voltage Propulsion Battery			✓	✓
Battery Control Modules			✓	✓
On-board Battery Charger			✓	✓

SEALS AND GASKETS

The **SEALS AND GASKETS** coverage is provided for all parts listed in the named component groups.

Supreme & Supreme Wrap

The **Supreme Plan** covers all original equipment factory installed mechanical and electrical parts and assemblies of your vehicle for mechanical breakdown, less any applicable deductible, except for the parts and services listed under "Exclusions."

The **Supreme "Wrap" Plan** covers all original Non-Powertrain factory installed mechanical and electrical parts and assemblies of your vehicle for mechanical breakdown, less any applicable deductible, except for the parts and services listed under "Exclusions."

Examples of parts and services not covered are: Reprogramming or software updates, adjustments and cleaning, 12 volt battery and cables, accessory and/or remote batteries, drive belts, coolant and vacuum hoses, brakes: brake drums, shoes, linings, disc rotors and pads, exhaust system (including catalytic converter), filters, fluids (except in conjunction with a covered repair), glass, lights (bulbs, LED, sealed beams and lenses), lubricants, manual clutch components, shock absorbers or struts, spark plugs and wires, squeaks and rattles, tune-ups, wheel balancing and alignment, wiper blades, coolant, wheels, wheel studs, door and window handles, cellular phones, any component or equipment not installed by the vehicle manufacturer and maintenance services recommended by your vehicle manufacturer.

* Covered if damaged by the failure of an internal part.